





## Using Duo Video


### Origination of Duo Video Using the Tandberg Remote Control

Note: The Duo Video is only available when connected to another site in an active call.

<p><b><u>Using the Presentation Button:</u></b></p> <p><b>1. If you are sending the PC press the blue "Presentation" button.</b></p> <p>This should automatically start the duo stream and send out the PC.</p> <p><b>Note:</b> Most sites with a Doc Cam are wired so the Doc Cam is connected through the PC port so this method will also work with those sites. The input can then be selected on the Doc Cam.</p> <p><b>2. Turn off the duo video by pressing the blue "Presentation" button again.</b></p>	
<p><b><u>Using the Tandberg Menus:</u></b></p> <p><b>1. Go to the "Presentation Menu" from the Main Menu screen.</b></p>	
<p><b>2. In the Presentation Menu, make sure the "Duo Video" tab is selected at the top.</b></p>	
<p><b>3. Select the source (i.e. PC)</b> Press the "OK" button on the remote to activate.</p> <p><b>4. Turn off the duo video by selecting the device again.</b></p>	

### Receiving Duo Video:

Tandberg units should be configured to automatically receive and display the duo video. When the stream is active, the monitor views should change automatically to show the duo stream in the large window and the near and far sites in smaller windows.



If you cannot see the duo video stream, call the VOC 1-800-863-3496.

**Special note for sites with monitor/projector configuration:** The projector must be in RGB mode to receive the duo video. When duo video content is being broadcast, the projector will show the duo video and the monitor will continue to show the main video (i.e., instructor camera) signal. When no duo video is being sent, the projector will display your local site camera.