



## THE TOOL FOR EACH PATTERN



### GINGHAM

The size of the gingham checks depends on the width of the teeth that are cut into a potter's rib.




### FAUX BOIS

An imprinted rocker makes fast work of applying a faux wood grain on any surface.

### RAW LINEN

A China bristle brush, with alternating sections clipped away with a utility knife, forges a coarse pattern.



### RAW SILK

Unraveling extra-coarse (#4) steel wool loosens its filaments, which make ultrafine stripes when pulled through a glaze.

### COMBED

Four patterns rim the edges of a compact square rubber combing tool, used to create straight combed patterns as well as the striated lengths in a faux-bois design.



### HERRINGBONE

A triangular rubber combing tool features the narrow teeth necessary to produce a herringbone pattern.



### FINE LINEN

The long, fine bristles of a horsehair flogger achieve the woven look of linen.





#### COLORS TO TRY

- 1. BASE COAT**  
Benjamin Moore  
2138-30 Mohegan Sage  
**GLAZE TINT**  
Benjamin Moore  
1524 Nature's Scenery
- 2. BASE COAT**  
Benjamin Moore  
2067-70 White Satin  
**GLAZE TINT**  
Benjamin Moore 438  
Spring Valley



#### PAINT THE HERRINGBONE

Using tape to mark 1-inch-wide sections eliminates the need for measuring.

- AFFIX** a length of 1-inch-wide painters' tape down the center of item (base coat should already be applied and dried).  
**AFFIX** 2 more lengths of the tape to one side of the first. Remove middle strip.  
**CONTINUE** taping off, using middle strip as a spacer, until every other length is exposed.  
**APPLY** a tinted glaze with a China bristle brush. Drag a triangular comb across surface at a 45-degree angle. Repeat until surface is covered. Let dry completely.  
**REMOVE** tape strips. Apply fresh tape over combed strips to cover them completely.  
**APPLY** a second coat of tinted glaze. Drag comb through it at opposite 45-degree angle.  
**LIFT** the tape, and the herringbone pattern will be revealed.



#### COMBED

#### COLORS TO TRY

- BASE COAT** Benjamin Moore 750 Seabrook  
**GLAZE TINT** Benjamin Moore 563 Douglas Fern  
Created by Matthew Axe, Thomas Eberharter, and Elana Frankel

SEE GUIDE FOR SOURCES

#### PAINT THE COMBED PATTERN

**USING** painters' tape, mark several 18-inch square sections on dried base coat using a pencil and a level.

- WORKING** in 1 square at a time, apply a thin layer of glaze with a China bristle brush.  
**PULL** the combing tool through the glaze.  
**REPEAT** in remaining sections, alternating direction of stripes with each square. Let dry.